
# SPAREPARTS LIST

## Electric Stacker PS 20D



Version 03/2015

From truck identification number:

30150319996

PS 20D-BPT-001-CHN

# Catalogue

Fig. 1 Label (for EU)....1
Fig. 2 Label (for US)....2
Fig. 3 Outline (Two-stage mast)....3
Fig. 4 Outline (Two-stage mast Full Free Lift)....5
Fig. 5 Pallet (Two-stage mast Normal/ Two-stage mast Full Free Lift)....6
Fig. 6 Chassis system (Two-stage mast Normal/ Two-stage mast Full Free Lift)....7
Fig. 7 Steering wheel assembly....9
Fig. 8 Push rod assembly....11
Fig. 9 Load roller assembly....13
Fig. 10 Truck body....14
Fig. 11 Power supply....16
Fig. 12 Indicator assembly....17
Fig. 13 Battery cover assembly....19
Fig. 14 Mast system (Two-stage mast Normal/ Full Free Lift)....20
Fig. 15 Mast lifting system (Two-stage mast Normal)....23
Fig. 16 Mast lifting system (Three-stage mast Full Free Lift)....25
Fig. 17 Hydraulic system (Two-stage mast Normal)....27
Fig. 18 Hydraulic system (Two-stage mast Full Free Lift)....30
Fig. 19 Cylinder (Two-stage mast Normal)....33
Fig. 20 Cylinder (Two-stage mast Full Free Lift)....35
Fig. 21 Chassis cylinder....37
Fig. 22 Manual steering wheel carrier....38
Fig. 23 Electric power assisted steering wheel carrier....40
Fig. 24 Electric steering assembly....42
Fig. 25 Drive wheel assembly 7EL-AC-1.3....44
Fig. 26 26EL-AC-1.3KW-R Drive wheel assembly....48
Fig. 27 Handle arm....52
Fig. 28 CANBUS Handle head....54
Fig. 29 Pump station system（3.0KW 3.2 delivery capacity）....56
Fig. 30 Pump station system（2.2KW 2.2 delivery capacity）....58
Fig. 31 Main circuit wiring (Electrical steering）....60
Fig. 32 Main circuit wiring（Manual steering）....61
Fig. 33 General electrical parts....62
Fig. 34 Electric control assembly(Electrical steering)....64
Fig. 35 Electric control assembly(Manual steering)....67
Fig. 36 Foldable platform....70
Fig. 37 Protective arm....72
Fig. 38 Backrest....74
Easy worn parts list....75

## Fig. 1 Label (for EU)





**Fig. 1 Label (for EU)**

| No. | Art No. | Description | Qty. | Note |
|---|---|---|---|---|
| A | 9000005967 | Crane hook label | 2 | |
| B | 9000003923 | Warning decal: Do not step under or on the forks | 2 | |
| C | 9000008650 | Residual lift capacity sticker | 1 | |
| D | 9000003573 | 'No passengers' decal | 1 | |
| E | 9000008561 | Never reach through | 1 | |
| F | 9000008649 | Identification plate | 1 | |
| G | 9000003570 | Sticker to read and follow these instructions | 1 | |
| L | 9000008555 | Filling sticker | 1 | |

## Fig. 2 Label (for US)





**Fig. 2 Label (for US)**

| No. | Art No. | Description | Qty. | Note |
|---|---|---|---|---|
| A | 9000005967 | Crane hook label | 2 | |
| B | 9000008555 | Filling sticker | 1 | |
| C | 9000008650 | Residual lift capacity sticker | 1 | |
| D | 9000003575 | Warning label | 1 | |
| E | 9000003577 | Warning label | 1 | |
| F | 9000008649 | Identification plate (ID-plate) | 1 | |
| G | 9000003570 | Sticker to read and follow these instructions | 1 | |
| H | 9000003579 | Warning label | 1 | |
| I | 9000003580 | Warning label | 1 | |
| J | 9000005970 | Warning label | 1 | |
| K | 9000005971 | Warning label | 2 | |

**Fig. 3 Outline (Two-stage mast)**




**Fig. 3 Outline (Two-stage mast)**

| No. | Art No. | Description | Qty. | Note |
|---|---|---|---|---|
| 1 | 9000008061 | Main cover | 1 | |
| 2 | 9000008063 | arm cover | 1 | With protective arm |
| | 9000008064 | | | Without protective arm |
| 3 | 9000008062 | Upper cover | 1 | |
| 4 | 9000008065 | Middle cover | 1 | |
| 5 | 9000008984 | Battery cover | 1 | |
| 6 | 9000011709 | Protective board | 1 | 2900 |
| | 9000011710 | | | 3200 |
| | 9000011711 | | | 3600 |
| | 9000011712 | | | 4000 |
| 7 | 9000007782 | Spring buckle | 10 | 2900<br>3200<br>3600 |
| | | | 12 | 4000 |
| 8 | 9000008972 | Upper protective board | 1 | |
| 9 | 1000423003 | Screw | 2 | M10×30 |
| 10 | 9000007793 | Screw | 1 | M10×10 |
| 1 | 9000007862 | Platform assembly | 1 | |
| 2 | 9000007891 | Protective arm assembly | 1 | |

## Fig. 4 Outline (Two-stage mast Full Free Lift)





**Fig. 4 Outline (Two-stage mast Full Free Lift)**

| No. | Art No. | Description | Qty. | Note |
|---|---|---|---|---|
| 1 | 9000008061 | Main cover | 1 | |
| 2 | 9000008063 | Protective arm cover | 1 | With protective arm |
| | 9000008064 | | | Without protective arm |
| 3 | 9000008062 | Upper cover | 1 | |
| 4 | 9000008065 | Middle cover | 1 | |
| 5 | 9000008984 | Battery cover | 1 | |
| 6 | 9000011713 | Protective board | 1 | 2900 |
| | 9000011714 | | | 3600 |
| | 9000013704 | | | 2700 |
| 7 | 9000007782 | Spring buckle | 8 | |
| 8 | 1000423003 | Screw | 2 | M10×30 |
| 9 | 9000007793 | Screw | 1 | M10×10 |
| 1 | 9000007862 | Platform assembly | 1 | |

| | | | | |
|---|---|---|---|---|
| 2 | 9000007891 | Protective arm assembly | 1 | |

**Fig. 5 Pallet (Two-stage mast Normal/ Two-stage mast Full Free Lift)**





**Fig. 5 Pallet (Two-stage mast Normal/ Two-stage mast Full Free Lift)**

| No. | Art No. | Description | Qty. | Note | Standard |
|---|---|---|---|---|---|
| 1 | 2220511001 | Compound roller | 4 | | |
| 2 | 2000435002 | Magnet steel | 1 | | |
| 3 | 9000008079 | Magnet steel seat | 1 | | |
| 4 | 0000024012 | Nut | 1 | M10 | GB/T6172.1=ISO4035 |
| 5 | 9000011715 | Pallet frame | 1 | 575X1150 | |
| | 9000011716 | | | 685X1150 | |

**Fig. 6 Chassis system (Two-stage mast Normal/ Two-stage mast Full Free Lift)**




**Fig. 6 Chassis System (Two-stage mast Normal/ Two-stage mast Full Free Lift)**

| No. | Art No. | Description | Qty. | Note | Standard |
|---|---|---|---|---|---|
| 1 | 0000023029 | Screw | 8 | M10×35 | GB/T70.1=ISO4762 |
| 2 | 0000023006 | Washer | 8 | 10 | GB/T93 |
| 3 | 0000025002 | Washer | 8 | 10 | GB/T95 |
| 4 | 2040400001 | Steering wheel assembly | 2 | | |
| 5 | 0000025032 | Washer | 6 | 12 | GB/T95 |
| 6 | 0000025024 | Washer | 6 | 12 | GB/T93 |
| 7 | 0000023082 | Screw | 4 | M12x35 | GB/T70.1=ISO4762 |
| 8 | 0000023156 | Screw | 2 | M12x25 | GB/T70.1=ISO4762 |
| 9 | 9000011744 | Sensor bar | 1 | | |
| 10 | 9000011717 | Guard board | 1 | | |
| 11 | 2220611001 | Compound roller | 4 | | |
| 12 | 9000011718 | Pallet | 1 | 575 | |
| | 9000011719 | | | 685 | |
| 13 | 0000024009 | Nut | 2 | M16 | GB/T6170=ISO4032 |
| 14 | 0000025029 | Washer | 2 | 16 | GB/T95 |
| 15 | 9000011720 | Adjusting block | 2 | | |
| 16 | 9000011721 | Base plate | N | | |
| 17 | 0000023056 | Screw | 4 | M4x12 | GB/T70.1=ISO4762 |
| 18 | 0000025019 | Washer | 4 | 4 | GB/T95 |
| 19 | 9000011722 | Adjusting block | 1 | | |
| 20 | 9000011723 | Assembly board | 1 | | |
| 21 | 0000023045 | Screw | 10 | M6x12 | GB/T70.2=ISO7380 |
| 22 | 9000011724 | Guard board | 1 | | |
| ① | 9000010408 | Steering wheel kit | 2 | | |

**Fig. 7 Steering wheel assembly**




**Fig. 7 Steering Wheel Assembly**

| No. | Parts No. | Item | Qty. | Note | Standard |
|---|---|---|---|---|---|
| 1 | 0000026008 | Circlip | 1 | 30 | GB/T894.1 |
| 2 | 2000405001 | Bearing seat | 1 | | |
| 3 | 0000027013 | Bearing | 2 | 7206C/DB | GB/T292 |
| 4 | 2000413001 | Sleeve | 1 | | |
| 5 | 0000026010 | Circlip | 1 | 62 | GB/T893.1 |
| 6 | 0000024015 | Lock nut | 1 | M14 | GB/T889.1=ISO7040 |
| 7 | 2000401007 | Rear wheel carrier | 1 | | |
| 8 | 0000023111 | Bolt | 1 | M14×100 | GB/T5782=ISO4014 |
| 9 | 2000413002 | Bushing | 1 | | |
| 10 | 1000525001 | Washer | 2 | | |
| 11 | 0000027001 | Bearing | 2 | 6204 | GB/T276 |
| 12 | 2020416001 | Castor | 1 | 124×60 | |
| 13 | 9000003638 | Castor | 2 | | |

**Fig. 8 Push rod assembly**




**Fig. 8 Push Rod Assembly**

| No. | Art No. | Description | Qty. | Note | Standard |
|---|---|---|---|---|---|
| 1 | 9000011725 | Lever block axle | 2 | | |
| 2 | 0000028009 | Dowel pin | 4 | 5x35 | GB/T879.1=ISO8752 |
| 3 | 0000013002 | Harness | 4 | 20X22X12 | |
| 4 | 9000011726 | Frame of roller | 2 | | |
| 5 | 0000027005 | Bushing | 16 | 20X22X12 | |
| 6 | 9000011727 | Push rod axle | 2 | | |
| 7 | 9000011728 | Push rod | 2 | | |
| 8 | 0000030001 | Grease nipple | 8 | 6 | JB/T7940.4=ISOB1575 |
| 9 | 1000413001 | Bushing | 4 | 20X23X15 | |
| 10 | 9000011729 | Large steel plate | 2 | | |
| 11 | 9000008631 | roller | 2 | | |
| 12 | 9000011730 | Fixing axle assembly | 2 | | |
| 13 | 1000523002 | Screw | 6 | M6X14 | |
| 14 | 9000008465 | Fixing axle | 4 | | |
| 15 | 9000011731 | Push rod kit | 2 | 1150 | |

**Fig. 9 Load roller assembly**





**Fig. 9 Load Roller Assembly**

| No. | Parts No. | Item | Qty. | Note | Standard |
|---|---|---|---|---|---|
| 1 | 2000405002 | Linking plate | 2 | | |
| 2 | 0000028009 | Dowel pin | 4 | 5×35 | GB/T879.1=ISO8752 |
| 3 | 2000407001 | Castor axle | 2 | | |
| 4 | 2000416002 | Load roller | 2 | 80×70 | |
| 5 | 0000027001 | Bearing | 4 | 6204 | GB/T276 |
| 6 | 0000030001 | Grease nipple | 2 | 6 | JB/T7940.4=ISOB1575 |
| 7 | 9000010398 | Load roller set | 2 | | |
| □1 | 2000600001 | Load roller assembly | 2 | | |

**Fig. 10 Truck body**




**Fig. 10 Truck Body**

| No. | Parts No. | Item | Qty. | Note | Standard |
|---|---|---|---|---|---|
| 1 | 9000007940 | Indicator assembly | 1 | | |
| 2 | 0000023020 | Screw | 4 | M6×20 | GB/T70.1=ISO4762 |
| 3 | 9000007791 | Screw | 4 | M10×35 | |
| 4 | 9000007783 | Nut | 13 | M10 | |
| 5 | 9000007790 | Screw | 2 | M10×55 | |
| 6 | 1000423003 | Screw | 1 | M10×30 | |
| 7 | 0000023029 | Screw | 4 | M10×35 | GB/T70.1=ISO4762 |
| 8 | 0000023006 | Washer | 8 | 10 | GB/T93 |
| 9 | 0000025002 | Washer | 8 | 10 | GB/T95 |
| 10 | 0000023034 | Screw | 4 | M10×20 | GB/T70.1=ISO4762 |
| 11 | 0000025024 | Washer | 4 | 12 | GB/T93 |
| 12 | 0000025032 | Washer | 4 | 12 | GB/T95 |
| 13 | 9000008240 | Board | 1 | | |
| 14 | 9000008069 | Electronic control assembly board | 1 | | |
| 15 | 9000007923 | Right vent assembly | 1 | | |
| 16 | 9000007920 | Left vent assembly | 1 | | |
| 17 | 0000023082 | Screw | 4 | M12×35 | GB/T70.1=ISO4762 |
| 18 | 0000023455 | Screw | 2 | M8×35 | GB/T70.1=ISO4762 |
| 19 | 0000024026 | Nut | 2 | M8 | GB/T6170=ISO4032 |
| 20 | 9000008241 | Truck body | 1 | Three-stage mast | |
| | 9000009082 | | | Two-stage mast | |
| 21 | 0000025010 | Washer | 1 | 6 | GB/T93 |
| 22 | 0000023053 | Screw | 1 | M6x12 | GB/T70.1=ISO4762 |
| 23 | 9000009545 | YGE hose clamp | 1 | | |

## Fig. 11 Power supply





**Fig. 11 Power Supply**

| No. | Art No. | Description | Qty. | Note | Standard |
|---|---|---|---|---|---|
| 1 | 0000023106 | Screw | 2 | M6×30 | GB/T70.1=ISO4762 |
| 2 | 0000023055 | Washer | 2 | 6 | GB/T95 |
| 3 | 9000010116 | Charger 24V/30A | 1 | Asia in Chinese | |
| | 9000010117 | | | Asia in English | |
| | 9000010118 | | | For EU | |
| | 9000010120 | | | For AUS | |
| | 9000010121 | | | For UK | |
| | 9000010146 | | | For USA | |
| 4 | 9000009083 | Power supply（210Ah） | 1 | welded type | |
| | 9000003990 | | | bolt type | |
| 5 | 9000008585 | Connector assembly（210Ah） | 1 | Only used for bolt type battery | |
| 6 | 9000009832 | Screw | 24 | | |

**Fig. 12 Indicator assembly**




**Fig. 12 Indicator Assembly**

| No. | Parts No. | Description | Qty. | Note | Standard |
|---|---|---|---|---|---|
| 1 | 0000023685 | Screw | 2 | M3×25 | GB/T818-2000=ISO7045 |
| 2 | 9000008516 | DC power switch | 1 | ZDK32-350 | |
| 3 | 0000024002 | Nut | 2 | M3 | GB/T6170=ISO4032 |
| 4 | 1000434025 | Indicator | 1 | CURTIS 803 | |
| 5 | 9000008326 | Key switch | 1 | LKS-101A | |
| 6 | 9000008519 | Key | 1 | | |
| 7 | 9000007938 | Plastic plate | 1 | | |
| 8 | 0000023215 | Screw | 2 | M5×10 | GB/T70.3=ISO10642 |
| 9 | 9000007939 | Fixing plate | 1 | | |
| 10 | 0090000272 | Screw | 4 | M4×12 | GB/T6560 |
| 11 | 9000008517 | Micro switch | 1 | | |
| 12 | 9000008515 | DC power switch | 1 | ZDK32-350 | |

## Fig. 13 Battery cover assembly





**Fig. 13 Battery Cover Assembly**

| No. | Parts No. | Item | Qty. | Note | Standard |
|---|---|---|---|---|---|
| 1 | 0000023073 | Screw | 2 | M4×10 | GB/T70.1=ISO4762 |
| 2 | 0000025018 | Washer | 2 | 4 | GB/T93 |
| 3 | 0000025019 | Washer | 2 | 4 | GB/T95 |
| 4 | 9000008795 | Pin | 1 | | |
| 5 | 0000023306 | Screw | 1 | M5×20 | GB/T70.1=ISO4762 |
| 6 | 0000025015 | Washer | 1 | 5 | GB/T93 |
| 7 | 0000025014 | Washer | 1 | 5 | GB/T95 |
| 8 | 0090000636 | Nut | 1 | M5 | GB/T6172.1=ISO4035 |

**Fig. 14 Mast system (Two-stage mast Normal/ Full Free Lift)**




**Fig. 14 Mast System (Two-stage mast Normal/ Full Free Lift)**

| No. | Art No. | Description | Qty. | Note | Standard |
|---|---|---|---|---|---|
| 1 | 9000011734 | Mast | 1 | Normal，2900;575x1150 | |
| | 9000011735 | | | Normal，3200;575x1150 | |
| | 9000011736 | | | Normal，3600;575x1150 | |
| | 9000011737 | | | Normal，4000;575x1150 | |
| | 9000011738 | | | Normal，2900;685x1150 | |
| | 9000011739 | | | Normal，3200;685x1150 | |
| | 9000011740 | | | Normal，3600;685x1150 | |
| | 9000011741 | | | Normal，4000;685x1150 | |
| | 9000011742 | | | Full Free，2900;575x1150 | |
| | 9000011743 | | | Full Free，3600;575x1150 | |
| | 9000011745 | | | Full Free，2900;685x1150 | |
| | 9000011746 | | | Full Free，3600;685x1150 | |
| | 9000013700 | | | Full Free，2700;575x1150 | |
| | 9000013701 | | | Full Free，2700;685x1150 | |
| 2 | 9000008973 | Mast | 1 | Normal，2900 | |
| | 9000008974 | | | Normal，3200 | |
| | 9000008975 | | | Normal，3600 | |
| | 9000008976 | | | Normal，4000 | |
| | 9000013802 | | | Full Free，2900 | |
| | 9000013803 | | | Full Free，3600 | |
| | 9000013705 | | | Full Free，2700 | |
| 3 | 0000023056 | Screw | 6 | M4x12 | GB/T70.1=ISO4762 |
| 4 | 0000025018 | Washer | 4 | 4 | GB/T93 |
| 5 | 0000025019 | Washer | 6 | 4 | GB/T95 |
| 6 | 9000008981 | Limit block | 2 | | |
| 7 | 2040511001 | Compound roller | 4 | | |
| 8 | 9000011744 | Sensor bar | 1 | | |

| | | | | | |
|---|---|---|---|---|---|
| 9 | 9000009080 | protective plate | 2 | | |
| 10 | 0000025014 | Washer | 4 | 5 | GB/T95 |
| 11 | 0000023311 | Screw | 4 | M5x10 | GB/T70.1=ISO4762 |
| 12 | 0000023067 | Screw | 2 | M8x16 | GB/T70.1=ISO4762 |
| 13 | 9000011772 | damping pad | 2 | | |

**Fig. 15 Mast lifting system (Two-stage mast Normal)**




**Fig. 15 Mast Lifting System (Two-stage mast Normal)**

| No. | Parts No. | Item | Qty. | Note | Standard |
|---|---|---|---|---|---|
| 1 | 0000023510 | Screw | 2 | M16x35 | GB/T77=ISO4026 |
| 2 | 0000024014 | Nut | 2 | M16x1.5 | GB/T6173=ISO8675 |
| 3 | 2010310001 | Chain wheel | 1 | | |
| 4 | 0000027012 | Bearing | 2 | 6206 | GB/T276 |
| 5 | 2000302002 | Adjusting washer | 2 | 2 | |
| 6 | 0000023158 | Screw | 2 | M10x30 | GB/T70.1=ISO4762 |
| 7 | 0000023006 | Washer | 2 | 10 | GB/T93 |
| 8 | 0000025002 | Washer | 2 | 10 | GB/T95 |
| 9 | 2030301001 | Chain wheel axle assembly | 1 | | |
| 10 | 0000023103 | Screw | 1 | M6x8 | GB/T70.3=ISO10642 |
| 11 | 2010305001 | Chain wheel carrier | 1 | | |
| 12 | 0000028011 | Split pin | 2 | 3x40 | GB/T91=ISO1234 |
| 13 | 9000008983 | Chain pulling bar | 1 | | |
| 14 | 0000024042 | Nut | 2 | M16x1.5 | GB/T6171=ISO8673 |
| 15 | 0000028010 | Split pin | 2 | 2x20 | GB/T91=ISO1234 |
| 16 | 0000028014 | Hinge pin | 2 | 8x40 | GB/T882=ISO2341 |
| 17 | 0000029012 | Chain LH1244x91 | 1 | 2900 | GB/T6074=ISO4347 |
| | 0000029013 | Chain LH1244x99 | | 3200 | GB/T6074=ISO4347 |
| | 0000029014 | Chain LH1244x109 | | 3600 | GB/T6074=ISO4347 |
| | 0000029015 | Chain LH1244x119 | | 4000 | GB/T6074=ISO4347 |
| 18 | 2010302001 | Cylinder fixing plate | 1 | | |
| 19 | 0000023101 | Bolt | 1 | M12x25 | GB/T5783=ISO4017 |
| 20 | 2010319001 | Damping pad | 1 | | |
| 21 | 9000009005 | Chain pulling bar | 1 | | |

**Fig. 16 Mast lifting system (Three-stage mast Full Free Lift)**




**Fig. 16 Mast Lifting System (Three-stage mast Full Free Lift)**

| No. | Parts No. | Item | Qty. | Note | Standard |
|---|---|---|---|---|---|
| 1 | 0000023067 | Screw | 8 | M8x16 | GB/T70.1=ISO4762 |
| 2 | 0000025001 | Washer | 6 | 8 | GB/T93 |
| 3 | 0000025011 | Washer | 6 | 8 | GB/T95 |
| 4 | 9000009003 | Holder | 1 | 1 | |
| 5 | 9000009002 | Holder | 1 | 2 | |
| 6 | 2010305001 | Chain wheel carrier | 2 | | |
| 7 | 2030301001 | Chain wheel axle assembly | 2 | | |
| 8 | 0000023103 | Screw | 2 | M6x8 | GB/T70.3=ISO10642 |
| 9 | 2010310001 | Chain wheel | 2 | | |
| 10 | 0000027012 | Bearing | 4 | 6206 | GB/T276 |
| 11 | 2000302002 | Adjusting washer | 4 | 2 | |
| 12 | 9000009001 | Pulling bar seat | 2 | | |
| 13 | 2000301002 | Pulley carrier | 1 | | |
| 14 | 0000025031 | Washer | 1 | 20 | GB/T95 |
| 15 | 0000026003 | Circlip | 1 | 20 | GB/T894.1 |
| 16 | 2000310002 | Pulley | 1 | | |
| 17 | 0000028011 | Split pin | 4 | 3x40 | GB/T91=ISO1234 |
| 18 | 9000009005 | Chain pulling bar | 4 | | |
| 19 | 0000024042 | Nut | 8 | M16x1.5 | GB/T6171=ISO8673 |
| 20 | 0000028010 | Split pin | 8 | 2x20 | GB/T91=ISO1234 |
| 21 | 0090000484 | Chain LH1244x61 | 2 | 2900 | GB/T6074=ISO4347 |
| | 0000029017 | Chain LH1244x69 | | 3600 | GB/T6074=ISO4347 |
| | 0000029016 | Chain LH1244x59 | | 2700 | GB/T6074=ISO4347 |
| 22 | 0000028060 | Short axle | 4 | 8x35 | GB/T882=ISO2341 |
| 23 | 0000025098 | Washer | 4 | 16 | GB/T849 |
| 24 | 0000025099 | Washer | 4 | 16 | GB/T850 |
| 25 | 2010319001 | Damping pad | 2 | | |

**Fig. 17 Hydraulic system (Two-stage mast Normal)**




**Fig. 17 Hydraulic System (Two-stage mast Normal)**

| No. | Art No. | Description | Qty. | Note | Standard |
|---|---|---|---|---|---|
| 1 | 0000023090 | Screw | 4 | M6×35 | GB/T70.1=ISO4762 |
| 2 | 9000008867 | DC power unit | 1 | 3200/3600/4000 | |
| | 9000013696 | DC power unit | | 2900 | |
| 3 | 0000023044 | Screw | 2 | M8×20 | GB/T70.1=ISO4762 |
| 4 | 0000025001 | Washer | 2 | 8 | GB/T93 |
| 5 | 0000025011 | Washer | 2 | 8 | GB/T95 |
| 6 | 2000303001 | Hydraulic cylinder cover | 1 | | |
| 7 | 9000008249 | Cylinder | 1 | | |
| 8 | 9000007832 | G straight joint | 1 | | |
| 9 | 9000007838 | Steering linking joint | 2 | | |
| 10 | 9000010282 | Special hose assembly | 1 | | |
| 11 | 9000008987 | Steel pipe | 1 | | |
| 12 | 9000008324 | YGE hose clamp | 1 | | |
| | 9000009545 | | 1 | | |
| 13 | 0000023042 | Screw | 2 | M6×10 | GB/T70.1=ISO4762 |
| 14 | 9000012428 | Special hose assembly | 1 | | |
| 15 | 9000007842 | Straight joint | 5 | | |
| 16 | 2000337001 | Safety valve | 2 | | |
| 17 | 9000008960 | Cylinder assembly | 1 | 2900 | |
| | 9000008961 | | | 3200 | |
| | 9000008962 | | | 3600 | |
| | 9000008963 | | | 4000 | |
| 18 | 9000011747 | Oil return hose | 1 | 2900 | |
| | 9000011748 | | | 3200 | |
| | 9000011749 | | | 3600 | |
| | 9000011750 | | | 4000 | |
| 19 | 9000010307 | Anti-vibration pad | 1 | | |
| 20 | 2010317003 | Joint | 1 | | |
| 21 | 9000013690 | Solenoid valve | 2 | | |
| 22 | 9000011751 | Hydraulic valve | 1 | | |
| 23 | 0090000020 | Screw | 2 | M6x40 | GB/T70.1=ISO4762 |
| 24 | 0000023082 | Screw | 1 | M12x35 | GB/T70.1=ISO4762 |
| 25 | 0000025024 | Washer | 1 | 12 | GB/T93 |
| 26 | 9000011752 | Chassis cylinder assembly | 1 | | |

| | | | | | |
|---|---|---|---|---|---|
| 27 | 9000011753 | Chassis cylinder steel pipe | 1 | | |
| 28 | 0000023055 | washer | 3 | 6 | GB/T95 |
| 29 | 9000011773 | throttle valve | 1 | | |

**Fig. 18 Hydraulic system (Two-stage mast Full Free Lift)**




**Fig. 18 Hydraulic System (Two-stage mast Full Free Lift)**

| No. | Art No. | Description | Qty. | Note | Standard |
|---|---|---|---|---|---|
| 1 | 0000023090 | Screw | 4 | M6×35 | GB/T70.1=ISO4762 |
| 2 | 9000008867 | DC power unit | 1 | 3600 | |
| | 9000013696 | | | 2900 | |
| 3 | 0000023044 | Screw | 2 | M8×20 | GB/T70.1=ISO4762 |
| 4 | 0000025001 | Washer | 2 | 8 | GB/T93 |
| 5 | 0000025011 | Washer | 2 | 8 | GB/T95 |
| 6 | 2000303001 | Hydraulic cylinder cover | 1 | | |
| 7 | 9000008249 | Cylinder | 1 | | |
| 8 | 9000007832 | G straight joint | 1 | | |
| 9 | 9000007838 | Steering linking joint | 2 | | |
| 10 | 9000010282 | Special hose assembly | 1 | | |
| 11 | 9000008987 | Steel pipe | 1 | | |
| 12 | 9000008324 | YGE hose clamp | 1 | | |
| | 9000009545 | | 1 | | |
| 13 | 0000023042 | Screw | 2 | M6×10 | GB/T70.1=ISO4762 |
| 14 | 0000023055 | Washer | 6 | 6 | GB/T95 |
| 15 | 9000013689 | Special hose assembly | 1 | | |
| 16 | 9000008887 | T steering linking joint | 1 | | |
| 17 | 0000023053 | Screw | 2 | M6x12 | GB/T70.1=ISO4762 |
| 18 | 0000025010 | Washer | 2 | 6 | GB/T93 |
| 19 | 2000302005 | Oil hose pallet | 1 | | |
| 20 | 9000008992 | Cylinder assembly | 2 | 2900 | |
| | 9000008993 | | | 3200 | |
| | 9000013699 | | | 2700 | |
| 21 | 0000023101 | Bolt | 2 | M12x25 | GB/T5783=ISO4017 |
| 22 | 0000025032 | Washer | 2 | 12 | GB/T95 |
| 23 | 9000008888 | 90° hydraulic hose assembly | 1 | 2900 | |
| | 9000005537 | | | 3600 | |
| | 9000013687 | | | 2700 | |
| 24 | 9000009004 | Steel pipe | 1 | | |
| 25 | 0000024068 | Nut | 1 | M6 | GB/T6170=ISO4032 |
| 26 | 9000007842 | Straight joint | 6 | | |
| 27 | 2000337001 | Safety valve | 3 | | |
| 28 | 9000010307 | Anti-vibration pad | 1 | | |
| 29 | 0000023310 | Bolt | 1 | M6x20 | GB/T5783=ISO4017 |

| | | | | | |
|---|---|---|---|---|---|
| 30 | 9000013690 | Solenoid valve | 2 | | |
| 31 | 9000011751 | Hydraulic valve | 1 | | |
| 32 | 0090000020 | Screw | 2 | M6x40 | GB/T70.1=ISO4762 |
| 33 | 0000023082 | Screw | 1 | M12x35 | GB/T70.1=ISO4762 |
| 34 | 0000025024 | Washer | 1 | 12 | GB/T93 |
| 35 | 9000011752 | Chassis cylinder assembly | 1 | | |
| 36 | 9000011753 | Chassis cylinder steel pipe | 1 | | |
| 37 | 9000011773 | throttle valve | 1 | | |

**Fig. 19 Cylinder (Two-stage mast Normal)**




**Fig. 19 Cylinder (Two-stage mast Normal)**

| No. | Parts No. | Item | Qty. | Note | Standard |
|---|---|---|---|---|---|
| 1 | 9000009922 | Piston rod | 1 | 2900 | |
| | 9000009923 | | | 3200 | |
| | 9000009924 | | | 3600 | |
| | 9000009925 | | | 4000 | |
| 2 | 9000009926 | Dust cover | 1 | 40x48x5/6.5 | |
| 3 | 9000009927 | Support ring of axle | 1 | 40X44X10 | |
| 4 | 9000009928 | Cylinder | 1 | 2900 | |
| | 9000009929 | | | 3200 | |
| | 9000009930 | | | 3600 | |
| | 9000009931 | | | 4000 | |
| 5 | 9000009932 | O ring | 1 | 44.4X3.1 | |
| 6 | 9000009933 | Support ring of hole | 1 | 45X50X10 | |
| 7 | 9000009934 | O ring | 2 | 24.4X3.1 | |
| 8 | 9000009178 | Y ring of hole | 1 | 40X50X6/7 | |
| 9 | 9000009935 | Piston | 1 | | |
| 10 | 0000025100 | Washer | 1 | 24 | GB/T93 |
| 11 | 0000024072 | Nut | 1 | M24x1.5 | GB/T6171=ISO8673 |
| 12 | 9000009936 | Cover | 1 | | |
| □1 | 9000009943 | Cylinder seal kit | 1 | | |

**Fig. 20 Cylinder (Two-stage mast Full Free Lift)**




**Fig. 20 Cylinder (Two-stage mast Full Free Lift)**

| No. | Parts No. | Item | Qty. | Note | Standard |
|---|---|---|---|---|---|
| 1 | 9000009937 | Piston rod | 1 | 2900 | |
| | 9000009938 | | | 3600 | |
| 2 | 9000009926 | Dust cover | 1 | 40x48x5/6.5 | |
| 3 | 9000009927 | Support ring of axle | 1 | 40X44X10 | |
| 4 | 9000009939 | Cylinder body | 1 | 2900 | |
| | 9000009940 | | | 3600 | |
| 5 | 9000009932 | O ring | 1 | 44.4X3.1 | |
| 6 | 9000009933 | Support ring of hole | 1 | 45X50X10 | |
| 7 | 9000009934 | O ring | 2 | 24.4X3.1 | |
| 8 | 9000009178 | Y ring of hole | 1 | 40X50X6/7 | |
| 9 | 9000009941 | Piston | 1 | | |
| 10 | 0000025033 | Washer | 1 | | GB/T93 |
| 11 | 0000024074 | Nut | 1 | M20x1.5 | GB/T6171=ISO8673 |
| 12 | 9000009942 | Guide bushing | 1 | | |
| □ | 9000009944 | Cylinder seal kit | 2 | | |

## Fig. 21 Chassis cylinder





**Fig. 21 Chassis Cylinder**

| No. | Art No. | Description | Qty. | Note |
|---|---|---|---|---|
| 1 | 9000009076 | Dust cover | 1 | 45X53X5/6.5 |
| 2 | 9000011760 | Circlip | 1 | 45X50X2 |
| 3 | 9000009078 | Seal ring | 1 | 45X55X6/7 |
| 4 | 9000011756 | End cap | 1 | |
| 5 | 9000008957 | Circlip | 1 | 55X60X1.5 |
| 6 | 9000011761 | O ring | 1 | 54.4X3.1 |
| 7 | 9000009077 | Copper bushing | 1 | 45X50X30 |
| 8 | 9000011757 | Cylinder body | 1 | |
| 9 | 9000011758 | Piston | 1 | |
| 10 | 9000011755 | Piston rod | 1 | |
| □1 | 9000011759 | Cylinder seal kit | 1 | |

**Fig. 22 Manual steering wheel carrier**




**Fig. 22 Manual Steering Wheel Carrier**

| No. | Parts No. | Item | Qty. | Note | Standard |
|---|---|---|---|---|---|
| 1 | 0000023042 | Screw | 8 | M6×10 | GB/T70.1=ISO4762 |
| 2 | 0000025010 | Washer | 8 | 6 | GB/T93 |
| 3 | 2000202006 | End cover | 4 | | |
| 4 | 2000231001 | Spring | 4 | | |
| 5 | 2000207001 | Spring spindle | 4 | | |
| 6 | 0000023099 | Screw | 6 | M10×45 | GB/T70.1=ISO4762 |
| 7 | 0000023006 | Washer | 18 | 10 | GB/T93 |
| 8 | 0000025002 | Washer | 18 | 10 | GB/T95 |
| 9 | 2000202004 | Outer V block | 2 | | |
| 10 | 2000202008 | Roller | 24 | | |
| 11 | 2000202005 | Inner V block | 2 | | |
| 12 | 0000023025 | Screw | 6 | M10×40 | GB/T70.1=ISO4762 |
| 13 | 0000023099 | Screw | 6 | M10×45 | GB/T70.1=ISO4762 |
| 14 | 2000201005 | Wheel carrier | 1 | | |
| 15 | 2000202003 | Cushion block | 2 | | |
| 16 | 2000201004 | Supporting frame | 1 | | |
| 17 | 0090000602 | Screw | 4 | M10×25 | GB/T821 |
| 18 | 0000024012 | Nut | 4 | M10 | GB/T6172.1=ISO4035 |
| 19 | 9000008321 | Top plate | 1 | | |
| 20 | 0000023095 | Bolt | 2 | M14×60 | GB/T5783=ISO4017 |
| 21 | 2000223001 | Screw | 2 | M10×180 | |
| 22 | 2000208001 | Spring guide bushing | 2 | | |
| 23 | 2000231002 | Spring | 2 | | |
| 24 | 2000212001 | Spring guide rod | 2 | | |
| 25 | 0000025024 | Washer | 4 | 12 | GB/T93 |
| 26 | 0000023094 | Screw | 4 | M12×30 | GB/T70.1=ISO4762 |
| 27 | 0000023098 | Screw | 1 | M12×10 | GB/T70.1=ISO4762 |
| 28 | 0000025032 | Washer | 4 | 12 | GB/T95 |
| 29 | 9000008257 | Handle axle | 1 | | |
| 30 | 0000023172 | Screw | 10 | M8×30 | GB/T70.1=ISO4762 |
| 31 | 0000025001 | Washer | 10 | 8 | GB/T93 |
| 32 | 0000025011 | Washer | 10 | 8 | GB/T95 |
| 33 | 2000202001 | Limit block | 2 | | |
| 34 | 9000007774 | Vertical drive | 1 | 7EL-AC-1.3 | |
| □1 | 2000200003 | Spring assembly | 2 | | |

**Fig. 23 Electric power assisted steering wheel carrier**




**Fig. 23 Electric Power Assisted Steering Wheel Carrier**

| No. | Parts No. | Item | Qty. | Note | Standard |
|---|---|---|---|---|---|
| 1 | 0000023042 | Screw | 8 | M6×10 | GB/T70.1=ISO4762 |
| 2 | 0000025010 | Washer | 8 | 6 | GB/T93 |
| 3 | 2000202006 | End cover | 4 | | |
| 4 | 2000231001 | Spring | 4 | | |
| 5 | 2000207001 | Spring spindle | 4 | | |
| 6 | 0000023099 | Screw | 6 | M10×45 | GB/T70.1=ISO4762 |
| 7 | 0000023006 | Washer | 18 | 10 | GB/T93 |
| 8 | 0000025002 | Washer | 22 | 10 | GB/T95 |
| 9 | 2000202004 | Outer V block | 2 | | |
| 10 | 2000202008 | Roller | 24 | | |
| 11 | 9000007685 | Inner V block | 2 | | |
| 12 | 0000023025 | Screw | 6 | M10×40 | GB/T70.1=ISO4762 |
| 13 | 0000023099 | Screw | 6 | M10×45 | GB/T70.1=ISO4762 |
| 14 | 9000007680 | Wheel carrier | 1 | | |
| 15 | 2000202003 | Cushion block | 2 | | |
| 16 | 2000201004 | Supporting frame | 1 | | |
| 17 | 0090000602 | Screw | 4 | M10×25 | GB/T821 |
| 18 | 0000024012 | Nut | 4 | M10 | GB/T6172.1=ISO4035 |
| 19 | 2000202002 | Top plate | 1 | | |
| 20 | 0000023095 | Bolt | 2 | M14×60 | GB/T5783=ISO4017 |
| 21 | 2000223001 | Screw | 2 | M10×180 | |
| 22 | 2000208001 | Spring guide bushing | 2 | | |
| 23 | 2000231002 | Spring | 2 | | |
| 24 | 2000212001 | Spring guide rod | 2 | | |
| 25 | 0000025024 | Washer | 4 | 12 | GB/T93 |
| 26 | 0000023094 | Screw | 4 | M12×30 | GB/T70.1=ISO4762 |
| 27 | 0000023098 | Screw | 1 | M12×10 | GB/T70.1=ISO4762 |
| 28 | 0000025032 | Washer | 4 | 12 | GB/T95 |
| 29 | 9000007686 | Electronic steering assembly | 1 | | |
| 30 | 9000007779 | Drive wheel assembly | 1 | | |
| □1 | 2000200003 | Spring assembly | 2 | | |

**Fig. 24 Electric steering assembly**




**Fig. 24 Electric steering assembly**

| No. | Parts No. | Item | Qty. | Note | Standard |
|---|---|---|---|---|---|
| 1 | 9000007422 | Bearing seat | 1 | | |
| 2 | 9000000240 | Bearing | 2 | 65×50×7 | GB/T276 |
| 3 | 0000023042 | Screw | 3 | M6×10 | GB/T70.1=ISO476 |
| 4 | 0000023034 | Screw | 4 | M10×20 | GB/T70.1=ISO476 |
| 5 | 9000007423 | Fixing seat | 1 | | |
| 6 | 0000026043 | Circlip | 1 | 50 | GB/T894.1 |
| 7 | 9000007806 | Damper | 1 | | |
| 8 | 9000007421 | Transition linking block | 1 | | |
| 9 | 9000007693 | Potentiometer fixing plate | 1 | | |
| 10 | 0000023032 | Washer | 4 | 5 | GB/T95 |
| 11 | 0000025015 | Washer | 4 | 5 | GB/T93 |
| 12 | 0000023311 | Screw | 4 | M5×10 | GB/T70.1=ISO476 |
| 13 | 9000007424 | Linking block | 1 | | |
| 14 | 0000023073 | Screw | 4 | M4×10 | GB/T70.1=ISO476 |

**Fig. 25 Drive wheel assembly 7EL-AC-1.3**




**Fig. 25 Drive Wheel Assembly 7EL-AC-1.3**

| No. | Parts No. | Item | Qty. | Note | Standard |
|---|---|---|---|---|---|
| 1 | 9000009493 | Gear box | 1 | | |
| 2 | 9000009494 | Circlip | 1 | | |
| 3 | 0090000116 | Bearing | 1 | 30208 | GB/T297 |
| 4 | 0090000505 | Oil seal | 1 | 50×80×8 | GB/T9877 |
| 5 | 9000009496 | Bushing | 1 | | |
| 6 | 0000027031 | Bearing | 1 | 32010 | GB/T297 |
| 7 | 9000009497 | Adjusting washer | 1 | | |
| 8 | 9000009498 | Gear | 1 | | |
| 9 | 9000009499 | Drive wheel | 1 | | |
| 10 | 0090000117 | Dowel pin | 2 | 4×12 | GB/T119.1=ISO2338 |
| 11 | 9000009500 | Circlip | 1 | | |
| 12 | 9000009501 | Bolt | 1 | | |
| 13 | 0090000502 | Bearing | 1 | 32304 | GB/T297 |
| 14 | 0090000503 | Bearing | 1 | 32204 | GB/T297 |
| 15 | 9000009502 | Gear | 1 | | |
| 16 | 9000009503 | Outer thimble | 1 | | |
| 17 | 9000009504 | Inner thimble | 1 | | |
| 18 | 9000009505 | Adjusting washer | 1 | | |
| 19 | 9000009506 | Adjusting washer | 1 | | |
| 20 | 9000009507 | Bearing seat | 1 | | |
| 21 | 0000025012 | Washer | 8 | 5 | GB/T93 |
| 22 | 0000023675 | Screw | 4 | M5×16 | GB/T70.2=ISO7380 |
| 23 | 0000022036 | Combination washer | 3 | 12 | JB/T982 |
| 24 | 0090000506 | Plug | | | JB/ZQ4444 |
| 25 | 9000009508 | Big gear | 1 | | |
| 26 | 9000009509 | Washer | 1 | | |
| 27 | 0000025066 | Washer | 1 | 14 | GB/T856 |
| 28 | 0090000090 | Nut | 1 | M14×1.5 | GB/T6173=ISO8675 |
| 29 | 9000009510 | Washer | 1 | | |
| 30 | 9000009511 | Side cover | 1 | | |
| 31 | 9000009512 | Upper cover | 1 | | |
| 32 | 9000009513 | Dust cover | 1 | | |

**Fig. 25 Drive wheel assembly 7EL-AC-1.3**




Fig. 25 Drive wheel assembly 7EL-AC-1.3

| No. | Parts No. | Item | Qty. | Note | Standard |
|---|---|---|---|---|---|
| 33 | 9000009514 | Bolt | 5 | | |
| 34 | 9000009515 | Drive wheel | 1 | | |
| 35 | 0000028027 | Dowl pin | 2 | 6×30 | GB/T119.1=ISO2338 |
| 36 | 0000025006 | Washer | 22 | 6 | GB/T93 |
| 37 | 0000023020 | Screw | 11 | M6×20 | GB/T70.1=ISO4762 |
| 38 | 9000009495 | Vent plug | 1 | | |
| 39 | 9000009516 | Rotating support | 1 | | |
| 40 | 0000023106 | Screw | 6 | M6×30 | GB/T70.1=ISO4762 |
| 41 | 0090000504 | Dowel pin | 2 | 6×26 | GB/T119.1=ISO2338 |
| 42 | 0000022037 | O seal ring | 2 | 125×2.65 | GB/T3452.1=ISO3601-1 |
| 43 | 9000009517 | Small gear | 1 | | |
| 44 | 9000009518 | Drive motor | 1 | | |
| 45 | 9000009519 | Bushing | 1 | | |
| 46 | 0000026013 | Circlip | 1 | 25 | GB/T894.1 |
| 47 | 9000009520 | Brake | 1 | | |
| 48 | 9000009521 | Dust cover | 1 | | |
| 49 | 9000009522 | Flange | 2 | | |
| 50 | 9000009523 | Speed sensor gear | 1 | | |
| 51 | 9000009524 | Speed sensor | 1 | | |
| 52 | 9000009525 | Spacer | 1 | | |
| 53 | 0000023311 | Screw | 4 | M5×10 | GB/T70.1=ISO4762 |
| 54 | 0000022059 | O seal ring | 1 | 20×2.65 | GB/T3452.1=ISO3601-1 |
| 55 | 9000009526 | Bracket | 1 | | |
| 56 | 0000025001 | Washer | 3 | 8 | GB/T93 |
| 57 | 0000023047 | Screw | 3 | M8x25 | GB/T70.1=ISO4762 |
| 58 | 0000036003 | Flat key | 1 | A 6×18 | GB/T1096 |
| 59 | 0000026003 | Circlip | 1 | 20 | GB/T894.1 |
| 60 | 9000009527 | Dust cover | 1 | | |
| 61 | 0000023563 | Screw | 3 | M6×65 | GB/T70.1=ISO4762 |
| 62 | 9000009528 | Adjusting washer | 1 | | |
| 63 | 0000028137 | Dowel pin | 2 | 6×30 | GB/T879.1=ISO8752 |
| 64 | 0090000321 | Screw | 2 | M6×45 | GB/T70.1=ISO4762 |
| 65 | 0000022038 | O seal ring | 1 | 65X2.65 | GB/T3452.1=ISO3601-1 |

**Fig. 26 26EL-AC-1.3KW-R Drive wheel assembly**




**Fig. 26 26EL-AC-1.3KW-R Drive Wheel Assembly**

| No. | Parts No. | Item | Qty. | Note | Standard |
|---|---|---|---|---|---|
| 1 | 9000009493 | Gear box | 1 | | |
| 2 | 9000009494 | Circlip | 1 | | |
| 3 | 0090000116 | Bearing | 1 | 30208 | GB/T297 |
| 4 | 0090000505 | Oil seal | 1 | 50x80x8 | GB/T9877 |
| 5 | 9000009496 | Bushing | 1 | | |
| 6 | 0000027031 | Bearing | 1 | 32010 | GB/T276 |
| 7 | 9000009497 | Adjusting washer | 1 | | |
| 8 | 9000009498 | Gear | 1 | | |
| 9 | 9000009499 | Drive axle | 1 | | |
| 10 | 0090000117 | Dowel pin | 2 | 4x12 | GB/T119.2-2000 |
| 11 | 9000009500 | Circlip | 1 | | |
| 12 | 9000009501 | Bolt | 1 | | |
| 13 | 0090000502 | Bearing | 1 | 32304 | GB/T276 |
| 14 | 0090000503 | Bearing | 1 | 32204 | GB/T276 |
| 15 | 9000009502 | Gear | 1 | | |
| 16 | 9000009503 | Outer sleeve | 1 | | |
| 17 | 9000009504 | Inner sleeve | 1 | | |
| 18 | 9000009505 | Adjusting washer | 1 | | |
| 19 | 9000009506 | Adjusting washer | 1 | | |
| 20 | 9000009507 | Bearing seat | 1 | | |
| 21 | 0000025015 | Washer | 8 | 5 | GB/T93 |
| 22 | 0000023107 | Screw | 4 | M5x16 | GB/T70.1=ISO4762 |
| 23 | 0000022036 | Combination washer | 3 | 12 | JB/T982 |
| 24 | 0090000506 | Screw | 3 | M12x1.25 | JB/ZQ4444-2006 |
| 25 | 9000009508 | Big gear | 1 | | |
| 26 | 9000009509 | Washer | 1 | | |
| 27 | 0090000090 | Nut | 1 | M14x1.5 | GB/T6173=ISO8675 |
| 28 | 9000009511 | Side cover | 1 | | |
| 29 | 9000009513 | Dust cover | 1 | | |
| 30 | 9000009514 | Bolt | 5 | | |
| 31 | 9000009515 | Drive wheel | 1 | | |
| 32 | 0000025010 | Washer | 20 | 6 | GB/T93 |
| 33 | 0000023106 | Screw | 8 | M6x30 | GB/T70.1=ISO4762 |
| 34 | 9000009495 | Vent plug | 1 | | |
| 35 | 0090000504 | Dowel pin | 2 | 6x26 | GB/T119.1=ISO2338 |
| 36 | 0000022037 | O ring | 2 | 125x2.65 | GB/T3452.1=ISO3601-1 |
| 37 | 9000009517 | Small gear | 1 | | |
| 38 | 9000009824 | Paper washer | 1 | | |
| 39 | 9000009825 | Upper cover | 1 | | |
| 40 | 9000009826 | Steering big gear | 1 | | |
| 41 | 9000009745 | Rotating bearing | 1 | | |

**Fig. 26 26EL-AC-1.3KW-R Drive wheel assembly**




**Fig. 26 26EL-AC-1.3KW-R Drive wheel assembly**

| No. | Parts No. | Item | Qty. | Note | Standard |
|---|---|---|---|---|---|
| 42 | 0000025001 | Washer | 6 | 8 | GB/T93 |
| 43 | 0000023455 | Screw | 6 | M8x35 | GB/T70.1=ISO4762 |
| 44 | 0090000151 | Oil seal | 1 | | GB/T9877 |
| 45 | 9000009532 | Assembly board | 1 | | |
| 46 | 9000009827 | Motor | 1 | | |
| 47 | 0000023172 | Screw | 6 | M8x30 | GB/T70.1-2000 |
| 48 | 9000009522 | Flange | 2 | | |
| 49 | 9000009523 | Speed sensor gear | 1 | | |
| 50 | 9000009524 | Speed sensor | 1 | | |
| 51 | 9000009748 | Bushing | 1 | | |
| 52 | 9000008854 | Bushing | 1 | | |
| 53 | 0000026013 | Circlip | 1 | 25 | GB/T894.1 |
| 54 | 0000023311 | Screw | 4 | M5x10 | GB/T70.1=ISO4762 |
| 55 | 9000009525 | Spacer | 1 | | |
| 56 | 0000022059 | O seal ring | 1 | 20x2.65 | GB/T3452.1=ISO3601-1 |
| 57 | 9000009749 | Bushing | 1 | | |
| 58 | 0000036001 | Flat key | 1 | 6x16 | GB/T1096 |
| 59 | 0000026003 | Circlip | 1 | 20 | GB/T894.1 |
| 60 | 9000009521 | Dust cover | 1 | | |
| 61 | 9000009528 | Adjusting washer | 1 | | |
| 62 | 0000025066 | Washer | 1 | 14 | GB/T856 |
| 63 | 9000009750 | Brake | 1 | | |
| 64 | 0090000526 | Bolt | 3 | M6x20 | GB/T5782=ISO4014 |
| 65 | 0000023020 | Screw | 9 | M6x20 | GB/T70.1=ISO4762 |
| 66 | 9000006304 | Steering carbon brush | 1 | | |
| 67 | 9000009726 | Steering motor | 1 | | |
| 68 | 0090000119 | Screw | 8 | M6x22 | GB/T70.1=ISO4762 |
| 69 | 9000009828 | Steering small gear | 1 | | |
| 70 | 0000026040 | Circlip | 1 | 22 | GB/T894.1 |
| 71 | 0090000118 | Flat key | 1 | 6x28 | GB/T1096 |
| 72 | 0000023106 | Screw | 12 | M6x30 | GB/T70.1=ISO4762 |

**Fig. 27 Handle arm**




**Fig. 27 Handle Arm**

| No. | Parts No. | Item | Quantity | Note | Standard |
|---|---|---|---|---|---|
| 1 | 1100100001 | Canbus control tiller | 1 | | |
| 2 | 0000023232 | Bolt | 2 | M8×25 | GB/T5783=ISO4017 |
| 3 | 1000123003 | Screw | 4 | M4×8 | GB/T70.2=ISO7380 |
| 4 | 9000007926 | Cover board | 1 | Short tiller arm | |
| | 9000009961 | Long Cover board | | Long tiller arm | |
| 5 | 9000007925 | Handle arm | 1 | Short tiller arm | |
| | 9000009962 | Long tiller arm | | Long tiller arm | |
| 6 | 9000008327 | Proximity switch | 1 | | |
| 7 | 0000023075 | Screw | 2 | M3×20 | GB/T70.1=ISO4762 |
| 8 | 1000113001 | Harness | 2 | 17×19×11 | |
| 9 | 9000007928 | Tiller axle | 1 | | |
| 10 | 0000028003 | Dowel pin | 1 | 4×24 | GB/T879.1=ISO8752 |
| 11 | 1000123001 | Screw | 1 | M8×20 | |
| 12 | 9000007930 | Left handle cover | 1 | | |
| 13 | 1010121001 | Air spring | 1 | 400N S≥55 | |
| | 1000121001 | | | 450N S⩾55 | |
| 14 | 0000023005 | Lock nut | 2 | M10 | GB/T889.1=ISO7040 |
| 15 | 9000007929 | Handle seat | 1 | | |
| 16 | 9000007931 | Right handle cover | 1 | | |
| 17 | 0000023519 | Screw | 4 | M6×10 | GB/T70.2=ISO7380 |

**Fig. 28 CANBUS Handle head**




**Fig. 28 CANBUS Handle Head**

| No. | Parts No. | Item | Qty. | Note | Standard |
|---|---|---|---|---|---|
| 1 | 1010114001 | Left driving button | 1 | | |
| 2 | 1000114015 | Horn button | 1 | | |
| 3 | 1000131009 | Spring of horn button | 5 | | |
| 4 | 1000113004 | Bushing of camshaft | 2 | | |
| 5 | 1000137001 | Magnet | 4 | | |
| 6 | 1000131010 | Spring of emergency button | 4 | | |
| 7 | 0000023058 | Screw | 3 | | GB/T70.1=ISO4762 |
| 8 | 0000023057 | Screw | 2 | | GB/T70.1=ISO4762 |
| 9 | 0000025017 | Washer | 2 | | GB/T95 |
| 10 | 1010114003 | Right driving button | 1 | | |
| 11 | 1000107002 | Linking axle of driving button | 1 | | |
| 12 | 1000137002 | Circlip of PCB board | 1 | | |
| 13 | 1000134005 | Load sensor | 2 | | |
| 14 | 1000103012 | Upper part of handle | 1 | | |
| 15 | 1000103013 | Under part of handle | 1 | | |
| 16 | 1000114017 | Left lifting button | 1 | | |
| 17 | 1000137003 | Magnet assembly seat | 2 | | |
| 18 | 1000131011 | Torsional spring | 2 | | |
| 19 | 1000114018 | Spring assembly board of emergency button | 1 | | |
| 20 | 1000114020 | Emergency button | 1 | | |
| 21 | 1000114021 | Cover of option switch | 1 | | |
| 22 | 1000114022 | Right lifting button | 1 | | |
| 23 | 0000023060 | Screw | 1 | | GB/T845=ISO7049 |
| 24 | 1000134006 | LED bi-color light | 1 | | |
| 25 | 1000103014 | Assembly seat of LED bi-color light | 1 | | |
| 26 | 1000131012 | Torsional spring of right driving button | 1 | | |
| 27 | 1000131013 | Torsional spring of left driving button | 1 | | |
| 28 | 1100135001 | PCB | 1 | | |

**Fig. 29 Pump station system（3.0KW 3.2 delivery capacity）**




**Fig. 29 Pump Station System（3.0KW 3.2 delivery capacity）**

| No. | Parts No. | Item | Qty. | Note |
|---|---|---|---|---|
| 1 | 2040334001 | Pump contactor | 1 | |
| 2 | 9000003582 | Carbon brush(assembly) | 1 | |
| 3 | 9000003583 | Motor | 1 | |
| 4 | 2000323001 | Plug | 1 | |
| 5 | 2000300002 | Valve | 1 | |
| 6 | 2000335003 | Solenoid valve | 1 | |
| 7 | 2000335004 | Check valve | 1 | |
| 8 | 2000323002 | Screw | 4 | |
| 9 | 9000011773 | Flow control valve | 1 | 10L/min |
| 10 | 2000323003 | Bolt | 1 | |
| 11 | 2040315003 | Overflow valve | 1 | |
| 12 | 2000322004 | O ring | 1 | |
| 13 | 2000317008 | Oil return hose | 1 | |
| 14 | 2040317008 | Oil return hose | 1 | |
| 15 | 9000008874 | Gear pump 3.2cc/r | 1 | |
| 16 | 9000008873 | Oil suction hose | 1 | L=250.50mm |
| 17 | 2000300004 | Filter | 1 | |
| □1 | 9000008867 | DC power unit | 1 | Pump Station System 3.0Kw，3.2 delivery capacity |

**Fig. 30 Pump station system（2.2KW 2.2 delivery capacity）**




**Fig. 30 Pump Station System（2.2KW 2.2 delivery capacity）**

| No. | Parts No. | Item | Qty. | Note |
|---|---|---|---|---|
| 1 | 2000335001 | Pump contactor | 1 | |
| 2 | 2000335002 | Carbon brush(assembly) | 1 | Iskra |
| 3 | 2000334001 | Motor | 1 | Iskra |
| 4 | 2000323001 | Plug | 1 | |
| 5 | 2000300002 | Valve body | 1 | |
| 6 | 2000335003 | Solenoid valve | 1 | |
| 7 | 2000335004 | Check valve | 1 | |
| 8 | 2000323002 | Screw | 4 | |
| 9 | 9000011773 | Flow control valve | 1 | |
| 10 | 2000323003 | Bolt | 1 | |
| 11 | 2000335006 | Overflow valve | 1 | |
| 12 | 2000322004 | O ring | 1 | |
| 13 | 2000317008 | Oil return hose | 1 | |
| 14 | 2000317009 | Oil return hose | 1 | |
| 15 | 2000300003 | Gear pump | 1 | |
| 16 | 2000317010 | Oil suction hose | 1 | |
| 17 | 2000300004 | Filter | 1 | |
| □1 | 2000300001 | DC power unit | 1 | 2.2kw 2.2 delivery capacity (Iskra motor) |

## Fig. 31 Main circuit wiring (Electrical steering）





**Fig. 31 Main Circuit Wiring (Electrical steering）**

| No. | Art No. | Description | Qty. | Note |
|---|---|---|---|---|
| 1 | 9000008444 | Drive motor cable | 1 | |
| 2 | 9000008361 | Pump motor cable | 1 | |
| 3 | 9000008362 | Power supply cable | 1 | |
| 4 | 9000008371 | FU+ cable | 1 | |
| 5 | 9000008446 | Steering controller cable | 1 | |
| 6 | 9000008520 | Steering motor cable | 1 | |

## Fig. 32 Main circuit wiring（Manual steering）





**Fig. 32 Main Circuit Wiring（Manual steering）**

| No. | Art No. | Description | Qty. | Note |
|---|---|---|---|---|
| 1 | 9000008368 | Drive motor cable | 1 | |
| 2 | 9000008361 | Pump motor cable | 1 | |
| 3 | 9000008362 | Power supply cable | 1 | |
| 4 | 9000008371 | FU+ cable | 1 | |

**Fig. 33 General electrical parts**




**Fig. 33 General Electrical Parts**

| No. | Art No. | Description | Qty. | Note | Standard |
|---|---|---|---|---|---|
| 1 | 0000023083 | Screw | 4 | M3×8 | GB/T70.2=ISO7380 |
| 2 | 9000008332 | Magnet switch | 2 | HWK23 | |
| 3 | 0000023033 | Screw | 4 | M4×25 | GB/T70.1=ISO4762 |
| 4 | 2040634001 | Proximity switch | 2 | XZ-15GW22-B | |
| 5 | 9000010040 | Proximity switch protective cover AP-B | 2 | AP-B | |
| 6 | 9000011701 | Limit control wiring harness | 1 | | |
| 7 | 9000000239 | Handle sensor | 1 | BD-MS | |
| | 9000008448 | | | BD-MS-3 | |
| 8 | 0000025026 | Washer | 3 | 3 | GB/T95 |
| 9 | 0000023216 | Screw | 3 | M3×8 | GB/T818-2000=ISO7045 |
| 10 | 0000023056 | Screw | 4 | M4×12 | GB/T70.1=ISO4762 |
| 11 | 0000025019 | Washer | 4 | 4 | GB/T95 |
| 12 | 9000001159 | Sensor | 1 | BD-PS | |
| | 9000008451 | | 1 | BD-PS-3 | |
| 13 | 9000011700 | Main control wiring harness | 1 | | |
| | 9000011705 | | 1 | | |
| 14 | 9000011701 | Control wiring harness | 1 | | |
| 15 | 9000011754 | Proximity switch | 1 | NBN5-F7-E2 | |
| 16 | 0000023075 | Screw | 2 | M3x20 | GB/T70.1=ISO4762 |

**Fig. 34 Electric control assembly(Electrical steering)**




**Fig. 34 Electric Control Assembly(Electrical steering)**

| No | Parts No. | Name | Qty. | Note | Standard |
|---|---|---|---|---|---|
| 1 | 9000008069 | Controller assembly plate | 1 | | |
| 2 | 9000000235 | Controller | 1 | CURTIS1232E-212 | |
| 3 | 9000000236 | Steering controller | 1 | BD-SC-24/10 | |
| | 9000008584 | | | BD-SC-24/10-3 | |
| 4 | 9000008376 | Aluminium plate | 1 | | |
| 5 | 1020434002 | Wiring terminal | 1 | BD-M8 | |
| 6 | 9000008586 | Fuse seat | 1 | BD-2×10A-1 | |
| 7 | 1000434041 | Pump contactor | 1 | ACR01F-F 1C | |
| 8 | 9000007679 | Plug fixing frame | 1 | | |
| 9 | 1000434021 | Fuse seat | 1 | BD-1×10A | |
| 10 | 1000434006 | Traction motor contactor | 1 | C100/120 | |
| 11 | 9000008598 | Main contactor assembly plate | 1 | | |
| 12 | 1020434003 | Copper | 1 | | |
| 13 | 1000434007 | Fuse seat | 2 | SYY | |
| 14 | 1020434001 | Fuse | 1 | 200A | |
| 15 | 2210434004 | Fuse | 1 | 150A | |
| 16 | 9000008374 | Copper | 1 | | |
| 17 | 9000008373 | Copper | 1 | | |
| 18 | 1000434040 | Fuse | 1 | 10A | |
| 19 | 3042434014 | Fuse | 1 | 15A | |
| 20 | 0090000082 | Screw | 2 | M4×30 | GB/T70.1=ISO4762 |
| 21 | 0000025018 | Washer | 12 | 4 | GB/T93 |
| 22 | 0000025019 | Washer | 12 | 4 | GB/T95 |
| 23 | 0000023073 | Screw | 2 | M4×10 | GB/T70.1=ISO4762 |
| 24 | 0000023019 | Screw | 2 | M4×30 | GB/T818-2000=ISO7045 |

| | | | | | |
|---|---|---|---|---|---|
| 25 | 0000023307 | Screw | 4 | M4×10 | GB/T818-2000=ISO7045 |
| 26 | 0000023211 | Screw | 4 | M4×16 | GB/T818-2000=ISO7045 |
| 27 | 0000025010 | Washer | 9 | 6 | GB/T93 |
| 28 | 0000023055 | Washer | 9 | 6 | GB/T95 |
| 29 | 0000023478 | Screw | 5 | M6×12 | GB/T70.1=ISO4762 |
| 30 | 0000023923 | Screw | 4 | M6×18 | GB/T70.1=ISO4762 |
| 31 | 0000025001 | Washer | 12 | 8 | GB/T93 |
| 32 | 0000025011 | Washer | 11 | 8 | GB/T95 |
| 33 | 0000024086 | Nut | 12 | M8 | GB/T6170=ISO4032 |
| 34 | 0000023067 | Screw | 4 | M8×16 | GB/T70.1=ISO4762 |
| 35 | 0000023516 | Screw | 1 | M5×10 | GB/T818-2000=ISO7045 |
| 36 | 0000025015 | Washer | 1 | 5 | GB/T93 |
| 37 | 0000025014 | Washer | 1 | 5 | GB/T95 |
| 38 | 0000023070 | Screw | 2 | M3×25 | GB/T70.1=ISO4762 |
| 39 | 9000008356 | Controller | 1 | | |
| 40 | 9000008372 | Copper | 1 | | |
| 41 | 1000434015 | Horn | 1 | DC24V | |
| 42 | 0000023727 | Screw | 2 | M4×6 | GB/T818-2000=ISO7045 |

**Fig. 35 Electric control assembly(Manual steering)**




**Fig. 35 Electric Control Assembly(Manual steering)**

| No. | Parts No. | Name | Qty. | Note | Standard |
|---|---|---|---|---|---|
| 1 | 9000008375 | Controller assembly | 1 | | |
| 2 | 9000008069 | Electrical control assembly plate | 1 | | |
| 3 | 9000000235 | Controller | 1 | CURTIS1232E-2121 | |
| 4 | 1000434040 | Fuse | 1 | 10A | |
| 5 | 9000008376 | Aluminium plate | 1 | | |
| 6 | 1020434002 | Wiring terminal | 1 | BD-M8 | |
| 7 | 9000008586 | Fuse seat | 1 | BD-2×10A-1 | |
| 8 | 1000434041 | Pump contactor | 1 | ACR01F-F 1C DC24V | |
| 9 | 9000007679 | Plug fixing seat | 1 | | |
| 10 | 1000434006 | Traction motor contactor | 1 | C100/120 DC24V | |
| 11 | 9000008598 | Main contactor assembly plate | 1 | | |
| 12 | 1020434003 | Copper bar | 1 | | |
| 13 | 1000434007 | Fuse seat | 2 | SYY | |
| 14 | 1020434001 | Fuse | 1 | 200A | |
| 15 | 2210434004 | Fuse | 1 | 150A | |
| 16 | 9000008374 | Copper bar | 1 | | |
| 17 | 9000008373 | Copper bar | 1 | | |
| 18 | 0000025014 | Washer | 1 | 5 | GB/T95 |
| 19 | 0000023516 | Screw | 1 | M5×10 | GB/T818-2000=ISO7045 |
| 20 | 0000025015 | Washer | 1 | 5 | GB/T93 |
| 21 | 0000025018 | Washer | 12 | 4 | GB/T93 |
| 22 | 0000025019 | Washer | 12 | 4 | GB/T95 |
| 23 | 0000023073 | Screw | 2 | M4×10 | GB/T70.1=ISO4762 |
| 24 | 0000023019 | Screw | 2 | M4×30 | GB/T818-2000=ISO7045 |
| 25 | 0000023307 | Screw | 4 | M4×10 | GB/T818-2000=ISO7045 |
| 26 | 0000023211 | Screw | 4 | M4×16 | GB/T818-2000=ISO7045 |
| 27 | 0000025010 | Washer | 9 | 6 | GB/T93 |
| 28 | 0000023055 | Washer | 9 | 6 | GB/T95 |

| | | | | | |
|---|---|---|---|---|---|
| 29 | 0000023478 | Screw | 5 | M6×12 | GB/T70.1=ISO4762 |
| 30 | 0000023923 | Screw | 4 | M6×18 | GB/T70.1=ISO4762 |
| 31 | 0000025001 | Washer | 12 | 8 | GB/T93 |
| 32 | 0000025011 | Washer | 11 | 8 | GB/T95 |
| 33 | 0000024086 | Nut | 12 | M8 | GB/T6170=ISO4032 |
| 34 | 0000023067 | Screw | 4 | M8×16 | GB/T70.1=ISO4762 |
| 35 | 9000008372 | Copper bar | 1 | | |
| 36 | 1000434015 | Horn | 1 | DC24V | |
| 37 | 0000023727 | Screw | 2 | M4×6 | GB/T818-2000=ISO7045 |

**Fig. 36 Foldable platform**




**Fig. 36 Foldable platform**

| No. | Art No. | Description | Qty. | Note | Standard |
|---|---|---|---|---|---|
| 1 | 9000007867 | Pedal pad | 1 | | |
| 2 | 9000007869 | Rotating axle | 1 | | |
| 3 | 9000007799 | Harness | 4 | 20×23×16.5 | |
| 4 | 9000007863 | Pedal | 1 | | |
| 5 | 0000023555 | Screw | 2 | M6×16 | GB/T70.2=ISO7380 |
| 6 | 2000421001 | Air spring | 1 | | |
| 7 | 0000024014 | Nut | 1 | M16×1.5 | GB/T6173=ISO8675 |
| 8 | 9000007873 | Cam | 1 | | |
| 9 | 9000007866 | Cam shaft | 1 | | |
| 10 | 0000025012 | Washer | 2 | 5 | GB/T93 |
| 11 | 0000023032 | Washer | 2 | 5 | GB/T95 |
| 12 | 0000023107 | Screw | 2 | M5×16 | GB/T70.1=ISO4762 |
| 13 | 9000009799 | Switch transition plate | 1 | | |
| 14 | 9000008328 | Proximity switch | 1 | NBN5-F7- | |
| 15 | 0000023075 | Screw | 2 | M3×20 | GB/T70.1=ISO4762 |
| 16 | 9000007864 | Assembly seat | 1 | | |
| 17 | 0090000048 | Washer | 4 | 12 | GB/T97.1-2002 |
| 18 | 0000025024 | Washer | 4 | 12 | GB/T93 |
| 19 | 9000007874 | Line hanging board | 1 | | |
| 20 | 0000024006 | Lock nut | 4 | M12 | GB/T889.1=ISO704 |
| 21 | 0090000450 | Screw | 4 | M12×45 | GB/T70.2=ISO7380 |
| 22 | 9000007865 | Damping pad | 2 | | |
| 23 | 9000007872 | Anti-vibration pad | 2 | | |
| 24 | 9000007871 | Anti-vibration washer | 2 | | |
| 25 | 0000031001 | Spring | 8 | 16.3×31.5 | GB/T1972-2005 |
| 26 | 9000007870 | Bolt | 2 | | |
| 27 | 0000028033 | Split pin | 2 | 3.2×20 | GB/T91=ISO1234 |
| 28 | 9000007868 | Assembly seat cover | 1 | | |
| 29 | 0000025010 | Washer | 6 | 6 | GB/T93 |
| 30 | 0000023045 | Screw | 6 | M6×12 | GB/T70.2=ISO7380 |
| 31 | 9000008897 | Suspension components | 2 | | |

**Fig. 37 Protective arm**




**Fig. 37 Protective Arm**

| No. | Art No. | Description | Qty. | Note | Standard |
|---|---|---|---|---|---|
| 1 | 9000007895 | Right protective arm cover | 1 | | |
| 2 | 0090000448 | Screw | 5 | M8×20 | GB/T70.2=ISO7380 |
| 3 | 9000007896 | Left protective arm cover | 1 | | |
| 4 | 9000007894 | Protective arm | 1 | | |
| 5 | 9000007780 | Air spring | 1 | | |
| 6 | 0000023045 | Screw | 3 | M6×12 | GB/T70.2=ISO7380 |
| 7 | 0000025010 | Washer | 3 | 6 | GB/T93 |
| 8 | 9000007897 | Spring | 1 | | |
| 9 | 0000023075 | Screw | 2 | M3×20 | GB/T70.1=ISO4762 |
| 10 | 9000008329 | Proximity switch | 1 | NBN5-F7-E2 | |
| 11 | 0000025012 | Washer | 2 | 5 | GB/T93 |
| 12 | 0000023032 | Washer | 2 | 5 | GB/T95 |
| 13 | 0000023107 | Screw | 2 | M5×16 | GB/T70.1=ISO4762 |
| 14 | 9000009799 | Switch transition plate | 1 | | |
| 15 | 9000007892 | Protective arm seat | 1 | | |
| 16 | 0000023006 | Washer | 4 | 10 | GB/T93 |
| 17 | 0090000447 | Screw | 4 | M10×25 | GB/T70.2=ISO7380 |
| 18 | 9000007893 | Protective arm clamp block | 2 | | |
| 19 | 0000023099 | Screw | 4 | M10×45 | GB/T70.1=ISO4762 |

## Fig. 38 Backrest





**Fig. 38 Backrest**

| No. | Parts No. | Name | Qty. | Note | Standard |
|---|---|---|---|---|---|
| 1 | 9000008259 | Backrest frame | 1 | | |
| 2 | 0000023088 | Screw | 2 | M10×25 | GB/T70.1=ISO4762 |
| 3 | 0000025002 | Washer | 4 | 10 | GB/T95 |
| 4 | 0000023006 | Washer | 4 | 10 | GB/T93 |
| 5 | 0000023029 | Screw | 2 | M10×35 | GB/T70.1=ISO4762 |

## Easy worn parts list

| No. | Art No. | Description | Qty. | Fig./Position | Note |
|---|---|---|---|---|---|
| 1 | 2220511001 | Compound roller | 4 | Fig. 5/1 | Pallet |
| 2 | 9000010408 | Castor complete | 2 | Fig. 6/1 | Chassis system |
| 3 | 9000003638 | Castor | 2 | Fig. 7/13 | Steering wheel |
| 4 | 9000011731 | Push rod kit 1150 | 2 | Fig. 8/15 | Push rod assembly |
| 5 | 9000010398 | Load roller set | 2 | Fig. 9/7 | Load roller |
| 6 | 2040511001 | Compound roller | 4 | Fig. 14/7 | Mast system |
| 7 | 9000009943 | Cylinder seal kit | 1 | Fig. 19/1 | Two-stage mast Normal |
| 8 | 9000009944 | Cylinder seal kit | 2 | Fig. 20/1 | Two-stage mast Full Free Lift |
| 9 | 9000011759 | Cylinder seal kit | 1 | Fig. 21/1 | Chassis cylinder |
| 10 | 9000007806 | Damper | 1 | Fig. 24/7 | Electric steering |
| 11 | 1010121001 | Air spring | 1 | Fig. 27/13 | Handle |
| 12 | 1000121001 | | | | |
| 13 | 9000003582 | Carbon brush | 1 | Fig. 29/2 | Pump |
| 14 | 2000335002 | | | Fig. 29/2 | |
| 15 | 1020434001 | Fuse 200A | 1 | Fig. 34/14<br>Fig. 35/14 | Electric control |
| 16 | 2210434004 | Fuse 150A | 1 | Fig. 34/15<br>Fig. 35/15 | |
| 17 | 1000434040 | Fuse 10A | 1 | Fig. 34/18<br>Fig. 35/4 | |
| 18 | 3042434014 | Fuse 15A | 1 | Fig. 34/19 | |
| 19 | 9000007799 | Harness 20×23×16.5 | 4 | Fig. 36/3 | Foot pedal |
| 20 | 2000421001 | Air spring (S≥70) | 1 | Fig. 36/6 | |
| 21 | 9000008897 | Suspension components | 2 | Fig. 36/31 | |
| 22 | 9000007780 | Air spring (S≥36) | 1 | Fig. 37/5 | Protective arm |